

## MOUNT INSTRUCTIONS RaceME Mount Kit

- 1. Locate the lower A Pillar Grab Handle Bold Cover
- 2. Gently remove the cover by pulling firmly
- 3. Remove bolt with 10mm socket
- 4. Slide Ball Mount through the shell and install using the supplied m5x1.0 Bolt. DO NOT OVERTIGHTEN.
- 5. Push the monitor mount on the ball mount and tighten the cinch nut.
- 6. Monitor can now be installed in its permanent home.

